Home Router   WiMAX HOME 01

Connection Settings Guide

Thank you for applying for Asahi Net WiMAX 2+ Service.

To start using HOME 01, please configure connection settings following the steps ①-③ shown below.

① Insert au IC card to the router

Referring to *Insert the au IC card* in the *Setup Guide*, insert au IC card to the router.

* The *Setup Guide* included in the box is in Japanese.

The English *Setup Guide* is available in the following webpage.
https://www.necplatforms.co.jp/support/wimax/wh01/manual.html

② Connect to Wi-Fi

Referring to *Step ① Connecting to Wireless LAN (Wi-Fi)* in the *Setup Guide,* connect your devices (smartphones, computers, etc.) and the router with Wi-Fi.

* If you wish to connect to Wi-Fi by manual settings, please refer to *POINT① To Do Wireless LAN (Wi-Fi) Connections via Manual Settings* shown on the reverse side of the *Setup Guide.*

③ Turn on the router and configure APN settings

Referring to the *Steps to Configure APN Settings* on the reverse side of the page, configure APN settings.

* Please configure APN settings before you start using the router.

Proceed to the reverse side of the page

Settings completed

Steps to Configure APN Settings

* Please configure APN settings before you start using the router

STEP 1

Open the browser on your device and enter **192.168.179.1** in the address bar, then press the [Enter] key.

🔍 192.168.179.1

Alternatively, access by QR code.

WiMAX HOME

← PC用ページに戻ります

* This settings guide is based on computer browser. If you are using a smartphone browser, please tap
  ← *PC用ページに戻ります (To the PC-optimized page)* to switch to pc-optimized page.

STEP 2

Select *English* in the クイック設定*Web* (*Quick Setting Web*) page to switch to English display.

クイック設定Web

左メニューから詳細設定ボタンを押して、設定をスタートしましょう。

⑦ :ヘルプ表示

詳細設定TOPへ

装置情報

English

⑦ 最新状態に更新

ログイン *(Sign in)* window will appear. Enter as shown on the right and click ログイン *(SIGN IN)*.

ログイン

http://192.168.179.1
このサイトへの接続ではプライバシーが保護されません

ユーザー名 admin

パスワード ••••••

ログイン キャンセル

ユーザー名 (Username)
Enter admin.

パスワード (Password)
Enter Web PW shown on the label on the bottom of the router.

Click ログイン (*SIGN IN*).

STEP 3

Quick Setting Web

Press the Advanced Settings button from the left menu to start the configuration.

⑦:Show Tiphelp

Device Information

⑦ Refresh

Model Name ⑦ WiMAX HOME 01
Firmware Version ⑦ 1.2.0
Connection Status ⑦ Internet connection
Profile ⑦ Internet
Traffic Counter(monthly) ⑦ 0.00bytes/7GB
Traffic Counter(daily) ⑦ 0.27MB/10GB
Connection Time ⑦ 0:05:50
Current Time ⑦ 12:51

Simple Setup

Setting up the profile ⑦ Internet Apply

Scroll down and select *AN01** (①) in the *Setting up the profile* field in *Simple Setup* and click the *Apply* button (②).

* If you are using a fixed IP address, select *AN02.*

Simple Setup

① ②

Setting up the profile ⑦ AN01 ▼   Apply

Settings are completed.